

Table of Contents

Introduction

Company Profile	2
Product Model Descriptions	4
Receiving Instructions	5
Operating & Installation Instructions	6
. Cup Dispenser Installation Instructions	7
Cleaning & Sanitisation	9
Removal and Installation	14
. E & S Series Reservoir Removal Procedure	18
. DryGuard™ Installation & Removal Procedure	20

Trouble Shooting 22

Service & Repairs 24

. Refrigeration Repair System(RRS) Removal Procedure	24
. Replacing Hot Tank Auto Cutout & Manual Reset Procedure	27
. Hot Tank & Heater Assembly Replacement Procedure	29
. Replacing Compressor Relay & Overload Procedure	31
. Hot Tank Heater Replacement Procedure	34

Wiring Diagrams

Models: Cold Only, Cook & Cold	36
Models: Hot & Cold	37
Models: Avalanche Cold Only	38
Models: Avalanche Hot & Cold	39
Models: Avalanche ETS	40

Product Specification & Parts Listing

(Each model contains cooler specifications , performance data, exploded view and parts listing)

Model: Glacier 220-240VAC	41
Model: Mogul 220-240VAC	44
Model: Sierra 220-240VAC	47
Model: Summit 220-240VAC	50
Model: Nevada 220-240VAC	53
Model: Mirage 220-240VAC	56
Model: E2O 220-240VAC	59
Model: Avalanche 220-240VAC	65
Model: Pinnacle 220-240VAC	67
Model: Cascade 220-240VAC	74
Model: Blizzard 220-240VAC	78
Model: Iceberg 220-240VAC	79

Point-of-Use System(POU) 81

ETS System(Extra Hot) 91

Miscellaneous

Parts Accessories and Cleaning	92
(Ozonator, Crystal Brite, Crystal Cloth, Cup Dispenser, Crock-pot, Bottle Rack)	
DryGuard™, AquaFloII System, Crystal Guard	93

Order Form 94